THE CURB INLET FILTER







SALES@PSIENVIRO.COM | (800) 808-1774 | WWW.PSIENVIRO.COM

CURB INLET FILTER (CIF) INSTALLATION INSTRUCTIONS



1. If empty, fill the non-woven anchor pouch with clean gravel free from organic materials, clay balls, or other deleterious substances.



2. Locate the curb inlet you wish to protect.



3. Slide the weighted anchor pouch into the opening of the curb inlet.



4. Make sure the CIF is positioned tightly against the curb.



sales@psienviro.com | (800) 808-1774 www.psienviro.com



5. If a longer length is desired, simply connect two CIFs together using the coupler at one of the velcro ends of the filter.